

# Level Plus<sup>®</sup>

Magnetostrictive Liquid-Level Transmitters  
with Temposonics<sup>®</sup> Technology

## OPERATION AND INSTALLATION MANUAL

M-Series Model MR Analog Transmitter





## UNITED STATES

---

### GENERAL:

Tel: +1-919-677-0100  
Fax: +1-919-677-2343  
E-mail: [sensorsinfo@mts.com](mailto:sensorsinfo@mts.com)  
<http://www.mtssensors.com>

### MAILING AND SHIPPING ADDRESS:

MTS Systems Corporation  
Sensors Division  
3001 Sheldon Drive  
Cary, North Carolina, 27513, USA

### CUSTOMER SERVICE:

Tel: +1-800-457-6620  
Fax: +1-800-498-4442  
E-mail: [orders@mts.com](mailto:orders@mts.com)

### TECHNICAL SUPPORT AND APPLICATIONS:

24 Hour Emergency Technical Support  
Tel: +1-800-633-7609  
e-mail: [levelplus@mts.com](mailto:levelplus@mts.com)

### OFFICE HOURS (EST):

Monday - Thursday: 8:00 a.m. to 5:00 p.m.  
Friday: 8:00 a.m. to 4:00 p.m.

### REMITTANCE ADDRESS:

MTS Systems Corporation  
Sensors Division  
NW 5872  
P.O. Box 1450  
Minneapolis, MN, 55486-5872

### QUOTE AND CONTRACT TERMS & CONDITIONS:

The parties expressly agree that the purchase and use of Material and/or Services from MTS Sensors Division are subject to MTS' Terms and Conditions, in effect as of the date of this document, which are located at [http://www.mtssensors.com/fileadmin/media/pdfs/Terms\\_and\\_Conditions.pdf](http://www.mtssensors.com/fileadmin/media/pdfs/Terms_and_Conditions.pdf) and are incorporated by reference into this and any ensuing contract. Printed Terms and Conditions can be provided upon request by emailing [sensorsinfo@mts.com](mailto:sensorsinfo@mts.com) or if you prefer, go to <http://www.mtssensors.com/index> and click the Quote/Contract Terms and Conditions link at the bottom of the page to download the PDF.

## GERMANY

---

### GENERAL:

Tel.: +49-2351-9587-0  
Fax: +49-2351-56491  
e-mail: [info@mtssensor.de](mailto:info@mtssensor.de)  
<http://www.mtssensor.de>

### MAILING AND SHIPPING ADDRESS:

MTS Sensor Technologie, GmbH & Co. KG  
Auf dem Schüffel 9  
D - 58513 Lüdenscheid, Germany

### TECHNICAL SUPPORT AND APPLICATIONS:

Tel.: +49-2351-9587-0  
e-mail: [info@mtssensor.de](mailto:info@mtssensor.de)  
<http://www.mtssensor.de>

## JAPAN

---

### GENERAL:

Tel.: +81-42-775-3838  
Fax: +81-42-775-5516  
e-mail: [info@mtssensor.co.jp](mailto:info@mtssensor.co.jp)  
<http://www.mtssensor.co.jp>

### MAILING AND SHIPPING ADDRESS:

MTS Sensors Technology Corporation  
737 Aihara-cho, Machida-shi  
Tokyo 194-0211, Japan

### TECHNICAL SUPPORT AND APPLICATIONS:

Tel.: +81-42-775-3838  
Fax: +81-42-775-5512

## Model MR Operation and Installation Manual

### Reference Information

#### Notices used in this manual

---

This manual contains notices to highlight specific information as follows:

**Notes:**

These notices provide important tips, guidance, or advice.

**Important:**

These notices provide information that might help you avoid inconvenient or problem situations.

**Attention:**

These notices indicate possible damage to programs, devices, or data and is placed just before the instruction or situation in which damage could occur.

**Caution:**

These notices indicate situations that can be potentially hazardous to you. A Caution notice is placed just before a description of a potentially hazardous procedure, step, or situation.

#### Related publications

---

The following publications are listed below by part number followed by description and are available in Adobe Acrobat Portable Document Format (PDF) at <http://www.mtssensors.com/>. The documents below are only available in English.

- 550677 - Product Specification, Model MR Analog Transmitter
- 551103 - Level Plus Accessories Catalog
- 550731 - Component Replacement Guide
- 550904 - Application Datasheet Rigid
- 550905 - Application Datasheet Sanitary
- 550906 - Application Datasheet 7/8" Flex
- 551409 - Brief Operation Manual for Safe Use

#### How this manual is organized

---

- “Introduction”, provides an overview of the manual.
- “Terms and Definitions”, provides definitions of terms used in this manual.
- “Product Overview”, gives an overall product description for the Level Plus liquid-level transmitter, its specifications, use, output, and electronics.
- “Installation and Mounting”, provides detailed installation and mounting information.
- “Electrical Connections and Wiring Procedures”, provides engineering specifications and wiring diagrams to assist in the installation process.
- “Maintenance and Field Service”, provides guidelines for general float maintenance and procedures required for replacing the Model MR electronic module or level transmitter.
- “Troubleshooting”, provides a list of symptoms, their possible cause and the action to be taken when troubleshooting the transmitter.
- Setup using keypad display - describes modes of operation, LCD display functionality, alarm settings and how to calibrate the unit manually.
- Setup using HART® Field Communicator - provides procedures for setting 4 and 20 mA set points
- Setup using MTS Field Setup Software - provides software installation, parameter setup, and calibration procedures.
- “Agency Information” provides comprehensive listings of agency approvals and standards, installation drawings, labels and applicable protocols.

#### Getting information, help, and service

---

You can get the latest ordering information and software updates by visiting [www.mtssensors.com](http://www.mtssensors.com) website  
General contact information, shipping and office hours are available on page i.

## Contact information

General .....	i
Mailing and shipping address .....	i
Customer service .....	i
Technical support and applications .....	i
Office hours .....	i
Remittance address .....	i
Quote and contract terms and conditions .....	i

## Reference information

Notices used in this manual .....	ii
Related publications .....	ii
How this manual is organized .....	ii
Getting information, help, and service .....	ii

## Introduction

<b>Introduction</b> .....	<b>1</b>
<b>Public website support portal</b> .....	<b>1</b>

## Terms and Definitions

<b>Terms and definitions reference</b> .....	<b>2</b>
--	----------

## Model MR product overview

<b>Product overview</b> .....	<b>3</b>
Industries .....	3
Applications .....	3
Features .....	3
<b>Components</b> .....	<b>3</b>
Housings .....	3
Outer pipe configurations .....	4
Floats .....	5
Internal electronics .....	5
Accessories .....	5
<b>Theory of operation</b> .....	<b>6</b>
<b>Accuracy</b> .....	<b>6</b>
<b>Warranty</b> .....	<b>6</b>
<b>Model number identification</b> .....	<b>7</b>
KC .....	8
<b>Product specifications</b> .....	<b>9</b>

## Model MR transmitter installation and mounting

<b>Installation and mounting</b> .....	<b>10</b>
<b>Storage</b> .....	<b>10</b>
<b>Stilling wells and guide poles</b> .....	<b>10</b>
<b>Installation</b> .....	<b>10</b>
Rigid probe .....	10
Flexible probe .....	11
<b>Mounting</b> .....	<b>12</b>
Threaded flange mounting .....	12
Welded flange mounting .....	12
Sanitary Tri-Clamp mounting .....	13

## Electrical connections and wiring procedures

<b>Electrical connections and wiring procedures</b> .....	<b>14</b>
<b>Safety recommendations for installation</b> .....	<b>14</b>
<b>Recommended cable types</b> .....	<b>15</b>
Cable specifications .....	15
<b>Electrical conduit installation</b> .....	<b>15</b>
<b>Grounding</b> .....	<b>16</b>

## Maintenance and field service

<b>Maintenance and field service</b> .....	<b>17</b>
<b>General maintenance and field service requirements</b> .....	<b>17</b>
Float maintenance .....	17
Field service .....	17
Service / RMA policy .....	17

## Troubleshooting

<b>Troubleshooting procedures</b> .....	<b>17</b>
---	-----------

## Setup

<b>Quick start-up guide</b> .....	<b>18</b>
Before you begin .....	18
Quick start-up procedure .....	18
<b>Setup using keypad display</b> .....	<b>18</b>
Operation modes .....	18
LCD display and keypad (optional) .....	19
Alarm settings .....	19
Manual calibration .....	19
<b>Setup using HART field communicator</b> .....	<b>21</b>
Preparing the transmitter for re-calibration .....	21
Setting the low value .....	21
Setting the upper range value .....	21
<b>Setup using MTS Field Setup software</b> .....	<b>22</b>
Using the MTS Field Setup software .....	22
Advanced setup tab .....	23
Calibration tab .....	24
Output tab .....	24

## Agency Information

<b>Agency approvals</b> .....	<b>25</b>
<b>Hazardous area installation</b> .....	<b>25</b>
KC .....	25
Installation Drawing .....	26
Notes .....	27
Wiring and Connection .....	29
Labels .....	30
Special Conditions for Use .....	31
<b>Agency certifications</b> .....	<b>32</b>
KC .....	32



## Introduction

---

MTS is recognized as the pioneer, innovator and leader in magnetostrictive sensing. The new Level Plus® M-Series transmitter design represents a continuation of our on-going effort to provide effective, innovative and reliable products to the Liquid Level marketplace.

This manual will provide the following information about the Level Plus Model MR analog transmitter:

- Terms and definitions
- Product overview
- Installation and mounting
- Electrical connections and wiring procedures
- Maintenance and field service
- Troubleshooting
- Quick start-up guide
- Setup using the keypad display
- Setup using a HART® Field Communicator
- Setup using MTS Field Setup Software
- Agency information
- Product certifications

## Public website support portal

---

Visit our support portal at <http://www.mtssensors.com> for:

- Building Level Plus M-Series Model MR analog transmitter model numbers
- Latest documentation releases
- Detailed ordering information
- Latest software updates

## Terms and definitions reference

---

### F

---

**Flameproof** – Type of protection based on enclosure in which the parts which can ignite an explosive gas atmosphere are placed within, and which can withstand the pressure developed during an internal explosion of an explosive mixture, and which prevents the transmission of the explosion to the explosive gas atmosphere surrounding the enclosure.

### H

---

**HART®** – a *Bidirectional communication protocol* that provides data access between intelligent field instruments and host systems.

### I

---

**Interface** – *Noun*; The measurement of the level of one liquid when that liquid is below another liquid.

**Interface** – *Adj.*; The *Software Graphical User Interface (GUI)* that allows the user to access software protocols (*HART*).

**Intrinsic safety** – ‘Intrinsically safe’ - Type of protection based on the restriction of electrical energy within apparatus of interconnecting wiring exposed to potentially explosive atmosphere to a level below that which can cause ignition by either sparking or heating effects.

### N

---

**NEMA Type 4X** – A product *Enclosure* intended for indoor or outdoor use primarily to provide a degree of protection against corrosion, windblown dust and rain, splashing water, and hose-directed water; and to be undamaged by the formation of ice on the enclosure. They are not intended to provide protection against conditions such as internal condensation or internal icing.

**NPT** – *U.S. standard* defining tapered pipe threads used to join pipes and fittings.

### S

---

**Specific Gravity** – The *density ratio* of a liquid to the density of water at the same conditions.

**Model MR Operation and Installation Manual**  
**Product Overview, Components**

**Model MR product overview**

The Level Plus Model MR Liquid-Level transmitter is a continuous multi-functional magnetostrictive transmitter that provides product level, interface level, and temperature to the user via 4 to 20 mA current loops or HART. Magnetostrictive technology is one of the most accurate and repeatable level technologies available to date. MTS is the inventor and purveyor of magnetostrictive technology and has been serving the level industry for over 30 years.

**INDUSTRIES**

- Petroleum
- Liquid petroleum gas
- Pharmaceutical
- Food & beverage
- Chemical
- Wastewater

**APPLICATIONS**

- Tank farms
- Terminals
- Bullet tanks
- Separator tanks
- Battery tanks
- Storage tanks

**FEATURES**

- **3-in-1 measurement**
  - Product level
  - Interface level
  - Temperature
- No scheduled maintenance or recalibration
- Field repairable
- AMS Aware

**Components**


The Level Plus Model MR liquid level transmitter consists of four main components; a housing, outer pipe, float, and electronics. Varying the components of the transmitter allows the transmitter to be customized to almost any application.

**HOUSINGS**


Level Plus Model MR transmitters are available in three housing configurations; NEMA Type 4X 316L stainless steel, flameproof single and dual-cavity housings as shown below:




**NEMA Type 4X 316L stainless-steel housing**



**Single cavity flameproof housing**




**Dual cavity flameproof housing**




**Model MR Operation and Installation Manual**  
**Product Overview, Components**

**OUTER PIPE CONFIGURATIONS**


The outer pipe is constructed of a variety of configurations, shown below. Contact factory for other materials (such as Hastelloy C or Teflon).



**Figure 1.** 5/8 in. diameter rigid outer pipe of 316L stainless steel



**Figure 2.** 5/8 in. diameter rigid outer pipe of polished 316L stainless steel with sanitary process connection and end plug



**Figure 3.** 7/8 in. diameter flexible pipe of 316L stainless steel

## FLOATS


Model MR transmitters offer numerous floats for different applications such as stainless steel, 3-A sanitary, Hastelloy, Teflon, and Nitrophyl for both product level and interface level. To be able to accurately detect the interface level there needs to be a difference of at least 0.05 in specific gravities between the product and interface liquids. For detailed information about floats, refer to the 'Accessories Catalog', MTS part number 551103.

For assistance with selecting a specific float for your application, please contact *Technical Support* with the following information:

- Specific gravity of liquid(s) being measured
- Process temperature
- Process Opening Size
- Vessel pressure

For KC approval, Model MR transmitters should be used with a float having an offset weight and made of stainless steel or Hastelloy C. This allows the float to stay in contact with the pipe to prevent the buildup of an electrostatic charge. For detailed information about floats, refer to the 'Accessories Catalog', MTS part number 551103.

Non-metallic floats with a projected surface area of less than 5,000 mm<sup>2</sup> should only be used in Zone 0, Gas group IIA such as float part numbers 201643-2, 201649-2, 201650-2, 201109, 251115 and 251116. All other non-metallic floats offered by MTS such as, 251939, 251119, 251120 and 252999, should not be used in a hazardous area application.

NITROPHYL FLOATS Float and dimension reference	Projected surface area	Part number
	2356 mm <sup>2</sup>	201643-2
		201649-2
		201650-2
TEFLON FLOATS Float and dimension reference	Projected surface area	Part number
	4635 mm <sup>2</sup>	201109
		251115
		251116

## INTERNAL ELECTRONICS

All transmitters come with two electronic components of a sensing element and a board set. All sensing elements up to 300 inches (7620 mm) are rigid and greater lengths have flexible sensing elements. Flexible sensing elements are only available under 300 inches (7620 mm) as special orders. The board set consists of a electronic puck and interconnect board. The board set can be configured for single or dual loop output offering the ability to output the product level, interface level, and temperature. All three variables can be communicated via HART.

The electronic puck can be ordered with or without a display. The optional display is capable of displaying the product level, interface level, and temperature. Designed into the optional display are three push buttons for local setup of 4 and 20 mA set points.

A temperature sensing function is optional with the Model MR transmitter. The temperature sensing device is a Resistive Temperature Device (RTD) mounted inside the transmitter's outer pipe assembly. The RTD is a 1000 ohm platinum film device.


## ACCESSORIES

MTS also offers a series of displays, housings, converters, and other accessories, please refer to the 'Accessories Catalog', MTS part number 551103.

## Theory of operation

Magnetostrictive M-Series transmitters precisely sense the position of an external float by applying an interrogation pulse to a waveguide medium. This current pulse causes a magnetic field to instantly surround the waveguide. The magnet installed within the float also creates a magnetic field. Where the magnetic fields from the waveguide and float intersect, a rotational force is created (waveguide twist). This, in turn, creates a torsional-sonic pulse that travels along the waveguide as shown in *Figure 4*.

The head of the transmitter houses the sensing circuit, which detects the torsional-sonic pulse and converts it to an electrical pulse. The distance from a reference point to the float is determined by measuring the time interval between the initiating current pulse and the return pulse and precisely knowing the speed of these pulses. The time interval is converted into a level measurement.



**Figure 4.** Theory of operation

## Accuracy

For magnetostrictive transmitters inherent accuracy is measured in terms of non-linearity. Non-linearity is a measurement of any imperfections in the waveguide that are reflected in the linearity of the transmitter's output. MTS tolerances reflect a maximum non-linearity of 0.02% of full scale. MTS is able to achieve such strict tolerances by manufacturing all of its own waveguide from a proprietary alloy and testing 100% of all transmitters before shipping.

## Warranty

### Important:

Contact Technical Support or Customer Service for assistance if you suspect that the transmitter is not working correctly. Technical support can assist you with troubleshooting, part replacement, and *Returned Material Authorization* (RMA) information if required.

All M-Series transmitters come with a two year limited warranty from the factory shipment date. A *Return Materials Authorization* (RMA) number is required and must accompany any transmitter returns. Any unit that was used in a process must be properly cleaned in accordance with OSHA standards, before it is returned to the factory. A *Material Safety Data Sheet* (MSDS) must also accompany the transmitter that was used in any process.

**Model MR Operation and Installation Manual**  
**Product Overview - KC**

**Model number identification for KC approval**

<b>TRANSMITTER MODEL</b>		=	<input type="text" value="M"/>	1
<b>M</b>	= Magnetostrictive transmitter			
<b>TYPE</b>		=	<input type="text" value="R"/>	2
<b>R</b>	= Analog output level transmitter			
<b>APPROVAL AGENCY</b>		=	<input type="text"/>	3
<b>K</b>	= KC Approval			
<b>OUTPUT</b>		=	<input type="text"/>	4
<b>1</b>	= 4-20 mA Single loop with HART			
<b>2</b>	= 4-20 mA Dual loops with HART			
<b>HOUSING TYPE</b>		=	<input type="text"/>	5
<b>B</b>	= Single cavity (Flameproof IIB)			
<b>C</b>	= Dual cavity (Flameproof IIB)			
<b>D</b>	= Single cavity with display (Flameproof IIB)			
<b>E</b>	= Dual cavity with display (Flameproof IIB)			
<b>P</b>	= NEMA Type 4X, 316L stainless steel with cable (No approval)			
<b>ELECTRONICS MOUNTING</b>		=	<input type="text"/>	6
<b>1</b>	= Integral electronics			
<b>TRANSMITTER PIPE/HOSE</b>		=	<input type="text"/>	7
<b>B</b>	= Industrial end-plug with stop collar			
<b>C</b>	= Sanitary, T-bar, TB			
<b>D</b>	= Sanitary, drain-in-place, DP			
<b>E</b>	= Sanitary, clean-in-place, CP			
<b>F</b>	= Sanitary, drain-in-place, no hole, DN			
<b>H</b>	= Flexible w/bottom fixing hook (stainless steel only)			
<b>J</b>	= Flexible w/bottom fixing weight (stainless steel only)			
<b>K</b>	= Flexible w/bottom fixing magnet (stainless steel only)			
<b>MATERIALS OF CONSTRUCTION (WETTED PARTS) (Note: contact factory for other materials)</b>		=	<input type="text"/>	8
<b>1</b>	= Stainless steel, 1.4404			
<b>2</b>	= Stainless steel, 1.4404 electropolished			
<b>3</b>	= Hastelloy C			
<b>A</b>	= Teflon / FEP			
<b>PROCESS CONNECTION TYPE</b>		=	<input type="text"/>	9
<b>1</b>	= NPT, Adjustable fitting			
<b>4</b>	= Sanitary, welded			
<b>5</b>	= Sanitary, adjustable fitting			
<b>6</b>	= 150 lbs. welded RF flange			
<b>7</b>	= 300 lbs. welded RF flange			
<b>8</b>	= 600 lbs. welded RF flange			
<b>9</b>	= DIN flange welded according to specification			
<b>PROCESS CONNECTION SIZE</b>		=	<input type="text"/>	10
<b>A</b>	= ¾ in. (NPT for 5/8 in. pipe)			
<b>B</b>	= 1 in. (NPT for 7/8 in. hose)			
<b>C</b>	= 1½ in.			
<b>D</b>	= 2 in.			
<b>E</b>	= 2½ in.			
<b>F</b>	= 3 in.			
<b>G</b>	= 4 in.			
<b>H</b>	= 5 in. (except sanitary)			
<b>J</b>	= 6 in.			
<b>TEMPERATURE</b>		=	<input type="text"/>	11
<b>0</b>	= None			
<b>1</b>	= One RTD, fixed position 76 mm (3 in.) from the end of pipe			
<b>2</b>	= One RTD, customer defined position #			
<b>Note: #If this RTD option is selected, option "18 E" must also be selected</b>				
<b>UNIT OF MEASUREMENT</b>		=	<input type="text"/>	12
<b>M</b>	= Metric (millimeters) Encode length in millimeters if using metric (XXXXX mm)			
<b>U</b>	= US Customary (inches) Encode length in inches if ordering in US Customary (XXX.XX in.)			

**Product Overview**

## Model number identification for KC

_____	<b>LENGTH</b> (Order length based on unit of measurement)	_____ =	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	13-17
=	Rigid or Sanitary transmitter: 508 mm (20 in.) to 7620 mm (300 in.)	=	Teflon: 508 mm (20 in.) to 6096 mm (240 in.)					
=	Flexible transmitter: 3048 mm (120 in.) to 12,192 mm (480 in.)							
_____	<b>SPECIAL</b>	_____ =	<input type="text"/>					18
<b>S</b>	= Standard product							
<b>E</b>	= Engineering special (not affecting agency controlled parts or features)							

**Model MR Operation and Installation Manual**  
**Product Specifications**

**Model MR product specifications**

Parameters	Specifications
<b>LEVEL OUTPUT</b>	
<b>Measured variable:</b>	Product level and interface level
<b>Output signal / Protocol:</b>	4 to 20 mA with HART®, 1 or 2 loop
<b>Order length:</b>	<b>Flexible hose:</b> 3048 mm (120 in.) to 12200 mm (480 in.) Δ §  <b>Rigid pipe:</b> 508 mm (20 in.) to 7620 mm (300 in.) Δ §  <b>Sanitary pipe:</b> 508 mm (20 in.) to 7620 mm (300 in.) Δ § Δ Contact factory for longer lengths. § Order length equals the measurement range plus the inactive zone.
<b>Non-linearity:</b>	0.02% F.S. or 0.794 mm (1/32 in.)* * Whichever is greater
<b>Repeatability:</b>	0.01% F.S. or 0.381 mm (0.015 in.)* (any direction) † Contact factory for alternative materials.
<b>TEMPERATURE OUTPUT</b>	
<b>Measured variable:</b>	Single-point temperatures
<b>Type:</b>	4 to 20 mA from 1000Ω platinum RTD at 0 °C
<b>Repeatability:</b>	±0.1 °C (±0.18 °F)
<b>Temperature accuracy:</b>	±1.5 °C (±2.7 °F)
<b>Drift:</b>	±0.5 °C (±0.9 °F) per year
<b>ELECTRONICS</b>	
<b>Input voltage:</b>	10.5 to 36 Vdc
<b>Fail safe:</b>	High (21.4 mA), or Low (3.8 mA)
<b>Reverse polarity protection:</b>	Series diode
<b>Lightning/ Transient protection:</b>	<b>Stage 1:</b> Line-to-ground surge suppression; IEC 61000-4-5 <b>Stage 2:</b> Line-to-line and line-to-ground transient suppressors; IEC 61000-4-4
<b>CALIBRATION</b>	
<b>Zero adjust range:</b>	Anywhere within the active length
<b>Span adjust range:</b>	Full scale to 152 mm (6 in.) from zero

Parameters	Specifications
<b>ENVIRONMENTAL</b>	
<b>Enclosure rating:</b>	NEMA Type 4X
<b>Humidity:</b>	0 to 100% relative humidity, non-condensing
<b>Operating temperatures:</b>	<b>Electronics:</b> -40 °C (-40 °F) to 71 °C (160 °F) <b>Sensing element:</b> -40 °C (-40 °F) to 125 °C (257 °F) ◇ <b>Temperature element:</b> -40 °C (-40 °F) to 105 °C (221 °F) ◇ Contact factory for specific temperature ranges.
<b>Vessel pressure:</b>	<b>Industrial rigid pipe:</b> 1000 psi (70 bar) <b>Sanitary pipe:</b> 435 psi (30 bar) <b>Teflon pipe:</b> 100 psi (7 bar) <b>Flexible Hose:</b> 260 psi (18 bar)
<b>Materials:</b>	<b>Wetted parts:</b> 316L stainless steel † <b>Non-wetted parts:</b> 316L stainless steel, Epoxy coated aluminum † Contact factory for alternative materials.
<b>FIELD INSTALLATION</b>	
<b>Housing dimensions:</b>	<b>Single cavity:</b> 127 mm (5 in.) by 133 mm (5.25 in.) 123 mm (4.84 in.) O.D. <b>Dual cavity:</b> 127 mm (5 in.) by 177 mm (6.95 in.) 123 mm (4.84 in.) O.D. <b>NEMA Type 4X:</b> 81 mm (3.2 in.) by 123 mm (4.85 in.) O.D.
<b>MOUNTING</b>	
<b>Rigid pipe:</b>	¾ in. Adjustable MNPT fitting Flange or Tri-Clamp® Mount
<b>Flexible hose:</b>	1 in. Adjustable MNPT fitting Flange mount
<b>WIRING</b>	
<b>Connections:</b>	2-wire shielded cable or twisted pair, Daniel Woodhead 6-pin male connector, 4570 mm (180 in.) integral cable with pigtail
<b>ELECTRICAL CONNECTIONS</b>	
<b>Single and Dual Cavity:</b>	M20 FNPT conduit opening
<b>NEMA Type 4X:</b>	½ in. FNPT conduit opening
<b>DISPLAY</b>	
<b>Measured variables:</b>	Product level, interface level and temperature
<b>Size:</b>	13 mm (0.5 in.)
<b>Number of digits:</b>	16

**Product Overview**

## Installation and mounting

If the installation is going to occur in a hazardous area, completely read the Agency Information section before starting any work. The Agency Information outlines additional regulations that need to be followed in order for the installation to comply with hazardous area regulations.

This section contains information about storing your transmitter (prior to installation) and detailed procedures for installing and mounting your transmitter.

### Storage

If storage is required prior to installation, store indoors in a dry environment at ambient temperature range not exceeding -40 °C (-40 °F) to 71 °C (160 °F).

### Stilling wells and guide poles

Level Plus transmitters can be mounted in slotted or unslotted stilling wells but a slotted stilling well is always preferred. Using a unslotted stilling well will negatively affect performance of any level device as the level in the stilling well can differ from the level in the tank. The Level Plus transmitter can also be installed to one side of the stilling well to also allow for sampling and manual gauging from the same opening as the automatic tank gauging. Contact *Technical Support* for details.

Level Plus transmitters do not require a stilling well for installation. Our transmitters are installed in numerous tanks without stilling wells with no loss in performance due to our patented flexible waveguide and hose. A stilling well is highly recommended for agitated, turbulent, and/or fast filling tanks.

### Installation

The installation procedures below are illustrated using the adjustable NPT fitting for a threaded flange mount. The procedures will have to be slightly adjusted if using a welded flange or sanitary Tri-Clamp mount.

#### RIGID PROBE

##### Tools Required:

- Channel lock pliers
- Common screwdriver
- 5/32 in. Hex key (allen wrench)

##### Caution:

It is recommended that assembly and mounting of this transmitter should not be performed alone. To ensure proper and safe assembly of the M-Series transmitter, a minimum of two (2) individuals are recommended. Gloves are also recommended. In addition, PPE is required for work areas such as safety shoes, safety glasses, hard hat, and fire resistant clothing.

Perform the following steps to Install the Model MR transmitter:

1. Remove the stop collar and E-ring. With assistance, feed the rigid pipe through the hole of the removed tank flange until the flange is positioned near the top of the transmitter. Insert the threaded portion of the adjustable fitting into the customer supplied flange and tighten (apply pipe thread sealant if required). Be careful not to drop the flange as it can damage the transmitter.
2. Slide the product float onto the rigid pipe. Slide the interface float (optional) onto the rigid pipe. Install stop collar 2 inches from the bottom (see '**Note**' below). Do not drop the float(s) or allow them to free fall along the rigid pipe as damage may result.

##### Note:

The stop collar can be removed or adjusted based on the float selected for the application. Please consult the factory for more information.

3. Slide float(s) back down to the stop collar to prevent them from free falling during installation into the tank. Insert the rigid pipe (with floats) through the tank opening and lower the transmitter/float assembly into the tank until it rests on the bottom. **DO NOT DROP OR DAMAGE THE PIPE.**
4. Secure the flange onto the tank mount.
5. Pull the transmitter upward so the end plug is just resting on the floor of the tank. Tighten the adjustable fitting to hold the transmitter in place.
6. Terminate the field wire cables noting proper wire orientation.

## Model MR Operation and Installation Manual

### Installation, Mounting and Storage

#### FLEXIBLE PROBE

##### Caution:

When assembling and installing the Model MR transmitter, be careful not to allow the flexible hose to kink or be coiled in less than 16 in. (406.5 mm) diameter. It is recommended that assembly and mounting of this transmitter should not be done alone. To ensure proper and safe assembly of the Model MR transmitter, a minimum of two (2) individuals are recommended. Gloves are also recommended. PPE is required for work areas such as safety shoes, safety glasses, hard hat, and fire resistant clothing.

##### Tools Required:

- 9/16 in. Socket and ratchet
  - Channel lock pliers
  - 3/16 in. Hex key (allen wrench)
1. Remove the stop collar. With assistance, feed the flexible hose through the hole of the removed tank flange until the flange is positioned at the rigid section of pipe near the top of the transmitter. Insert the threaded portion of the adjustable fitting into the customer supplied flange and tighten (apply pipe thread sealant if required). Be careful not to drop flange on the flexible hose as damage may result.
  2. Slide the product float onto the flexible pipe. Slide the interface float (optional) onto the flexible pipe. Install stop collar 3 inches from the bottom of rigid section (see '**Note**' below). Do not drop float(s) or allow them to free fall along the flexible pipe as damage may result.

##### Note:

The stop collar can be removed or adjusted based on the float selected for the application. Please consult the factory for more information.

3. Mount the hook, weight, or the magnet to the welded end-plug section of the pipe (this is the bottom rigid section of the pipe) using the supplied nut, spacer and washer, tighten securely as shown in *Figure 5*. **For the magnet, remove washer before installing in tank.**




Figure 5. Bottom fixing hardware

#### DO NOT DROP OR DAMAGE THE PIPE

**Important:** Avoid kinking or bending the flexible pipe in less than 16 inch (406 mm) diameter or damage may result.

4. Slide float(s) back down to the stop collar to prevent them from free falling during installation into the tank. Insert the flex pipe and floats through the tank riser pipe and lower the transmitter/float assembly into the tank until it rests on the bottom. If you are using a bottom-fixing hook, fasten the hook to the appropriate customer-supplied mating hardware at the tank bottom.
5. Secure the flange onto the tank riser pipe.
6. Pull the transmitter upward to straighten the flexible pipe until the resistance of the weight, magnet, or hook is felt without raising the weight or magnet off the floor of the tank. Tighten the adjustable fitting to hold the transmitter in place.
7. Terminate the field wire cables noting proper wire orientation.

## Mounting

The method of mounting the transmitter is dependent on the vessel or tank in which it is being used, and what type of transmitter is being mounted. There are three typical methods for mounting; threaded flange mounting, welded flange mounting, and sanitary Tri-Clamp mounting.

### THREADED FLANGE MOUNTING

In most applications, the Model MR transmitter can be mounted directly to the tank or flange via a NPT threaded fitting, assuming there is a proper threaded connection available. If the float will not fit through the flange opening when the flange is removed, there must be some alternative means to mount the float on the transmitter from inside the vessel; this may require an access port nearby the entry point of the transmitter as shown in *Figure 6*.




Figure 6. Threaded flange mounting for rigid (shown) and flexible pipe

### WELDED FLANGE MOUNTING

The Model MR transmitter can also be mounted to a tank flange as shown in *Figure 7*. First, install float(s) onto the transmitter. Second, install the float retaining hardware on the tip of the transmitter. To complete the installation, mount the transmitter, flange and float(s) as a unit in to the tank.





Figure 7. Welded flange mounting for rigid and flexible (shown) pipe

## Model MR Operation and Installation Manual


### Tri-Clamp Mounting

#### SANITARY TRI-CLAMP MOUNTING

In sanitary applications, the Model MR transmitter is mounted to the tank using a standard sanitary connection and clamp as shown in *Figure 8*. In most cases it is not necessary to remove the float as the sanitary end-plug fitting is sized to allow installation with the float in place. Please note that some sanitary end-plug styles have float(s) permanently mounted as shown in *Figure 9*. To install the clamp, the transmitter and float(s) into the mating process connection and attach the sanitary Tri-Clamp.



**Figure 8.** M-Series Model MR transmitter. Tank mounted with sanitary connection



\*This end plug style has permanently mounted floats. Floats cannot be removed from pipe.

**Figure 9.** End-plug options for transmitters in a sanitary pipe application

## Electrical connections and wiring procedures

A typical intrinsically safe connection for the Level Plus Model MR transmitter includes protective safety barriers, a power supply and a reading or monitoring device. Refer to *Agency information* and *Brief Operation Manual for Safe Use* for detailed information.

A typical explosion proof connection for the Model MR transmitter includes a power supply and a reading or monitoring device connected using explosion proof conduit. Refer to *Agency information* and *Brief Operation Manual for Safe Use* for detailed information.

**Notes:**


For explosion proof installation, safety barriers are not required and wiring shall be installed in accordance with the National Electric Code ANSI/NFPA 70, Article 501-30 or the regional equivalent.

## Safety recommendations for installation

**Be sure to:**

1. Always follow applicable local and national electrical codes and observe polarity when making electrical connections.
2. Never make electrical connections to the M-Series transmitter with power turned on.
3. Make sure that no wire strands are loose or sticking out of the terminal block connection which could short and cause a problem.
4. Make sure that no wire strands, including shield, are in contact with the electronic module enclosure.
5. The electronics module enclosure is grounded through internal circuitry and is electronically isolated from the explosion-proof housing.

Refer to the safe operating power chart (see *Figure 10*), which shows the relationship between loop resistance and operating voltage.



**Figure 10.** Safe operating power chart

**Model MR Operation and Installation Manual**  
**Cable Types and Electrical Conduit Installation**

**Recommended cable types**

Refer to 'Table 1' below for general requirements of cable types for the Level Plus Model MR analog transmitter.

**CABLE SPECIFICATIONS**

Parameter	Specification
Minimum cable size	24 AWG or heavier (0.51 mm diameter) Contact factory for assistance selecting proper cable.
Cable type	Single pair shielded or multiple pair with overall shield
Maximum cable length	Twisted pair: 10,000 ft. (3,048 m) Multiple twisted pair: 5,000 ft. (1,524 m)
Maximum cable length formula	Use the following formula to determine the maximum cable length for a specific application:  Where: $L = [(65 \times 106) \div (R \times C)] - [(Cf + 10,000) \div C]$ L = Length in meters or feet R = Resistance in ohms, current sense resistance plus barrier resistance C = Cable capacitance in pF/ft, or pF/m Cf = Maximum shunt capacitance of smart field devices in pF  Example: Assume a high performing smart transmitter, a control system, and a single pair of shielded wires. R = 250 ohms C = 50 pF/ 0,3 m (ft) Cf = 5,000 pF  $L = [(65 \times 106) \div 250 \times 50] - [(5,000 + 10,000) \div 50]$  L = 1,494 m (4,900 ft.)

**Table 1.** Cable specification and parameters


**Electrical conduit installation**

**Important:**

Seal all conduits within 457mm (18 in.)

**Notes:**

1. Use a flameproof type conduit sealing fitting.
2. Tighten housing cover (both front and back covers if dual cavity) to full stop against the O-ring. Make sure O-ring(s) are present and clean.
3. Do not over-tighten compression fittings.
4. Use side conduit entry only.
5. In high humidity areas, use a breather drain type conduit sealing fitting to minimize moisture intrusion.



**Figure 11.** Electrical conduit installation

## Grounding

**Note:**

Grounding the transmitter through a threaded conduit connection does not provide sufficient ground.

There are two methods to provide an earth ground to the earth ground of the electronics. Refer to 'Table 2' for safety barrier references.

- Run an earth ground through the conduit and connect directly to the earth ground lug inside the housing.
- Run an earth ground directly to the ground lug on the outside of the housing.

## Maintenance and field service

This section contains information about post installation maintenance and provides an overview of MTS Sensors' repair and replacement procedures.

### General maintenance and field service requirements

**Notes:**

Please contact Technical Support or Customer Service for help when damage occurs in order to obtain a return materials authorization (RMA) number. Packages without a RMA number may be rejected. Any unit that was used in a process must be properly cleaned in accordance with OSHA standards, before it is returned to the factory. A Material Safety Data Sheet (MSDS) must accompany material that was used in any media.

#### FLOAT MAINTENANCE

Level Plus M-Series transmitters use magnetostrictive technology and only have one moving part—the float. This technology ensures no scheduled maintenance or recalibration is required. However, MTS recommends that you check the transmitter pipe annually for build up of process material. Floats should move freely along the pipe. If they do not, routine cleaning should be performed.

#### FIELD SERVICE

If damage does occur to a M-Series transmitter, the transmitter can be serviced in the field with replacement parts. All electronic parts can be changed in the field without having to open the process vessel. Please contact Technical Support and refer to the Transmitter Electronics Replacement Guide (MTS part no. 550731) for detailed steps of field replacement.

#### SERVICE / RMA POLICY

If the customer suspects their transmitter is damaged or not functioning correctly, call *MTS Technical Support* for further instruction. If it is necessary to return the transmitter to the factory, an RMA number is required and can only be issued by Technical Support. Product returns that do not include an RMA will be returned to the customer. MTS evaluates the transmitter and advises the customer whether a repair or replacement is necessary and any cost that might be incurred. If the customer declines repair/replacement or the transmitter has no fault found, the unit is sent back as is and the customer is charged with a standard evaluation fee.

If the transmitter is under warranty and a manufacturer's defect is detected, there will be no cost to the customer for repair or replacement. If the transmitter is out of warranty or if the customer has damaged the transmitter, a repair or replacement quote will be provided. In specific cases where the transmitter can not be removed and returned to the factory for evaluation, field evaluations can be performed in the field by an MTS technician. If field evaluation must be performed, the customer is responsible for all expenses incurred for travel, evaluation, parts and repair time. However, if the transmitter is under warranty and the problem is due to a manufacturer's defect, there is no cost to the customer for replacement parts. To discuss all service options, contact *Technical Support*.

## Troubleshooting

The table below contains troubleshooting information for the Model MR analog transmitter.

### TROUBLESHOOTING PROCEDURES

Symptom	Possible Cause	Action
No communication with transmitter	No power	Check voltage at transmitter
	Wiring incorrect	Reference installation drawing (see 'Electrical connections and wiring')
	Wrong software	Confirm correct software
Output in Alarm (3.8 mA or 21.4 mA)	Float not recognized	Confirm that the float is attached
	Float is in the dead zone	Raise float to see if the error stops
	Wrong number of floats selected	Confirm that the number of floats on the transmitter and the number of floats the transmitter is attempting to verify are the same.

**Table 3.** Troubleshooting reference

## Quick start-up guide

### BEFORE YOU BEGIN

**Note:**

Output will vary depending on the location of the 4 and 20 mA set points.

**Tools Needed:**

- 24 Vdc linear regulated power supply
- Current Meter

### QUICK START-UP PROCEDURE

1. Connect 24 Vdc power supply
2. Turn on power supply
3. Connect Current Meter to test pins on the front of the puck
4. Move the float to the tip of the pipe and verify 4 mA output
5. Move the float to the top of the pipe and verify 20 mA output
6. If using two floats, repeat steps 4 and 5 for second float
7. Turn off power and disconnect power supply
8. Install in tank
9. Connect power and turn on

## Setup using keypad display

The Model MR transmitter can be calibrated by using the HART communications protocol or it may be manually calibrated using the optional keypad display. This section explains modes of operation and the steps you need to perform to calibrate your transmitter manually using the keypad display.

### OPERATION MODES

The Model MR transmitter runs in one of the following modes of operation. You can use these modes to calibrate and set up various operating parameters.

#### Run Mode

Run mode is the primary mode of operation. This mode will perform measurements, display data, and respond to HART commands. The run mode can be configured for various output options. The minimum configuration will only perform a single-level measurement. More complex configurations will perform a second float measurement (interface), or temperature measurements. Level measurement. More complex configurations will perform a second float measurement (interface), or temperature measurements.

#### Program Mode


The program mode is only applicable to Model MR transmitter with the keypad display option. Enter this mode by pressing any of the three keys, *Up keypad*, *Down keypad*, and *Enter keypad* as shown in Figure 12. Menus guide the user through various programming options. When in the program mode, HART communications are not functional. An automatic time out feature is provided so that the transmitter does not remain inadvertently in program mode.

#### Display Test Mode

This mode is invoked through the keypad.

### Display / Keypad usage in Program Mode

The Model MR transmitter can be configured by pressing three keys, the Up keypad, Down keypad, and Enter keypad as shown in Figure 13. This gives the user a means to calibrate and set up various operating parameters.



**Figure 13.** Keypad display

The three keypads are identified with “∇”, “Δ”, and “←”. The “Δ” keypad may be used to indicate Up responses, the “∇” symbol indicates Down responses, and “←” indicates an Enter response. Normally, the Model MR transmitter will remain in run mode. When you press any three keys, the transmitter will enter program mode. In program mode, the electronics module menu displays options that you can scroll through using the Up and Down keypads. To select an option, press Enter.

Setup

## Model MR Operation and Installation Manual

### Setup

#### Notes:

In program mode, the transmitter will not respond to incoming HART commands. This function will prevent a user at a remote terminal from overwriting a parameter that is being entered at the same time from a local site.

#### Program Mode Timer

After you enter the programming mode, a one-minute timer is started. Each time you press a button, the timer is reset. If you do not press a menu button within one minute, the timer will expire and the transmitter will return to the *run mode*.

#### Loop 1 and Loop 2 Test Ports


Using a standard multi-meter set the meter to DC current and attach across the terminals, loop current can be read directly from ports 1 and 2 (see *Figure 14*). The current read on the meter should correspond with the data being displayed. These ports allow the loop current to be read directly without having to interrupt power.

#### HART Port

This port allows for direct connection of the HART field calibrator or other HART host device as long as there is a load on loop 1.

### LCD DISPLAY AND KEYPAD (OPTIONAL)

A sixteen character, seven-segment LCD display and three push-button “keypad” option is available. Level and temperature measurements are displayed when in run mode. When power is applied to the unit, a start” message is displayed. Then, while in run mode, the display is updated every three seconds with new data. There are three data fields on the display [Level 1, Level 2, Temperature]. If a measurement is not available, there will be dashes ( - - - - ) shown in the corresponding field.



**Figure 14.** Keypad display LCD display

### ALARM SETTINGS

When a fault condition is detected by the internal microprocessor, the 4 to 20 mA current will go to the selected alarm mode. If in the 4 mA alarm mode when a fault is detected, the output will be continuous at  $3.8 \pm 0.1$  mA. If in the 20 mA alarm mode when a fault is detected, the output will be continuous at  $21.5 \pm 0.2$  mA.

### MANUAL CALIBRATION

The procedure to enter calibration mode and modify levels 1 and 2, adjust LCD contrast and perform a LCD test is shown in *Figure 15 on the next page*.




Figure 15. Manual calibration matrix

## Model MR Operation and Installation Manual

### Setup

## Setup using HART Field Communicator

Refer to the documentation that comes with the *Rosemount Model 275 and 375 Field Communicator* for specific sensor calibration information. This section describes how the HART protocol is applied to the Level Plus Model MR transmitter only.

Using the HART interface allows for calibration without having to remove the transmitter from the process and position of the floats. You can perform this function by using HART commands 35 and 65.

Any measured output may be assigned to any variable. Loop #1 is always the primary variable (PV); level 1 is usually assigned to loop 1. Loop 2 is always the Second Variable (SV); usually represents temperature or level 2. The Third Variable (TV) and Fourth Variable (FV) may be assigned to any remaining output such as, level 2, temperature. Analog output codes are 0, 1, and 2 respectively.

Calibration set points for level are given as the absolute displacement (in the appropriate units) from the tip of the sensor pipe. For example, if the Zero (LRV) position for level 1 is given as 5 inches, the transmitter will produce 4 mA when the float is 5 inches from the tip of the sensor pipe. If the Span (URV) position for level 1 is given as 30 inches, the transmitter will produce 20 mA when the float is 35 inches from the top of the sensor pipe. To calibrate the temperature set points, the Zero (LRV) and Span (URV) points are given in degrees. For temperature, the Zero (LRV) value (in degrees) must always be less than the Span (URV) value (in degrees).

### PREPARING THE TRANSMITTER FOR RE-CALIBRATION

The Model MR transmitter can be re-calibrated by using the model 275 and 375 Field Communicator. Complete the following procedure to reset the zero and span values for loop 1 (only loop 1 can be calibrated with the HART Field Communicator using the generic XMTR type driver. To access both loops as well as other parameters, the MTS device driver must be purchased and installed in to the 275/375 field communicator. For more information about the HART device driver, go to [HARTcomm.org](http://HARTcomm.org).

#### Attention:

DO NOT enter a high value that exceeds the active length of the sensor.

**Before you begin**, perform the following steps:

1. Connect the transmitter to a clean 24 Vdc power supply. Use a linear supply, switching types do not provide ripple-free power. HART cannot tolerate more than a 25 mV voltage ripple.
2. If the unit is installed in a live application, place your automatic controllers in manual mode and be advised that the output current will change during calibration.
3. Follow safe working procedures for working on live equipment in a hazardous location before you remove the housing cover.
4. Connect the HART Field Communicator to the terminals that are labeled HART located on the front panel display of the Level Plus transmitter.
5. Press the black and white I/O button on the HART terminal. The HART terminal will perform an automatic self test. The Main window displays. If the device is not connected properly, the message “No device found” displays.
6. In the Main window, press the **Key #1**, the Device Setup window displays.
7. In the Device setup window, press **Key #3**. The Basic Setup window displays.
8. In the Basic Setup window, press **Key #3**. The Range Values window displays.

### SETTING THE LOW VALUE

Complete the following steps to set the low value:

1. To set the low value, Process Variable, Low Range Value (PV LRV) to 4 mA, select Key #1. The PV LRV window displays the current low value. Below the highlighted value located under the current value, key in the low value you want (example 3.00 in. is shown; if 4 inches is the value you want, key in 4.) then, press Enter (F4) located below the LCD display.
2. To write the changed lower value to memory, press the Send key.
3. Two Warning messages will display before the new values take affect; if your new low values are correct, respond to the Warning messages by pressing OK when prompted. This action resets the Low Range Value, or 4 mA position into the transmitter’s memory.
4. Go back to the Range Values window to verify that the new parameters have been accepted into the transmitter’s memory.
5. **Do one of the following:**
  - 5a. Exit program mode.
  - 5b. To reset the upper value, continue with “Setting the Upper Range Value.

### SETTING THE UPPER RANGE VALUE

Complete the following steps to set the Upper Range Value:

**Caution:**

DO NOT enter a high value that exceeds the active length of the sensor.

1. Open the Range Values window. To set the 20 mA Upper Range Value, press Key #2. The Process Variable, Upper Range Value (PV URV) window displays.
2. As shown the Lower Value window, the current value displays with a highlighted number below the value displayed. To change the upper value, key in the new value. You can use whole numbers or whole numbers and decimals (example, 40 = 40 inches, or 40.5 = 40.50 inches.) Whole numbers will be converted as decimal equivalents automatically by the HART terminal.
3. Key in the new Upper Range Value and press Enter or (F4). The Range Values window displays.
4. Verify that the upper and lower values are correct. If the values are correct, press Send.
5. You will be prompted with two Warning messages, press OK in response to both warnings.

## Setup using MTS Field Setup software

Adjustments to the calibration and setup parameters of the transmitter may be done using the MTS Field Setup Software and a RS232 to HART converter (SMAR HI-311, MTS Part # 380068). Be sure to install the latest software package, go to [www.mtssensors.com](http://www.mtssensors.com) for more information.

### USING THE MTS FIELD SETUP SOFTWARE

**Tools Required:**

- HART adapter/converter
- 24 Vdc power supply
- PC

Complete the following steps to Install Setup Software

1. Insert the software installation CD into computer or go to [www.mtssensors.com](http://www.mtssensors.com) and download the latest software.
2. Open folder "Setup software Analog\_Digital"
3. Open folder "Analog"
4. Open file "M-Series Field Setup"
5. Follow on screen instructions

Complete the following steps to Install the hardware

1. Connect Power Supply to level transmitter
2. Connect HART adapter to level transmitter and PC

**Attention:**

Be sure loop #1 is connected to a load of 250 to 500 ohm. A transmitter installed in a control loop is a good example of the loop load. A 250 ohm load resistor may need to be added to the loop for HART to communicate effectively.

3. Turn on power
4. Open Setup Software. Data should fill in. If no data appears select a different serial communication port.

**Model MR Operation and Installation Manual**  
**Setup**

**ADVANCED SETUP TAB**



**Gradient** : A calibration factor that is specific to each level transmitter. This value should not be changed unless directed to do so by Technical Support.

**Length**: The order length of the transmitter. This value should not be changed unless directed to do so by Technical Support.

**Units**: The unit of measure for Length and Head Adder. This is used when writing new values of Length and Head Adder to the transmitter. Use the Output Tab to change units of measure for all data.

**Head Adder**: The distance between the sensing element and the order length. Each model has a slightly different head adder. This value should not be changed unless directed to do so by Technical Support.

Transmitter style	Length
NEMA 4X housing, standard rigid pipe	4.3 to 4.5 in (109 to 114 mm)
Single or Dual Cavity Housing, standard rigid pipe	5.6 to 5.7 in (142 to 145 mm)
NEMA 4X housing, flexible hose	14.0 to 14.5 in (356 to 368 mm)
Single or Dual Cavity Housing, flexible hose	14.0 to 14.5 in (356 to 368 mm)


**Display Units**: Units used only on LCD display of units, mA, or percent  
**Float #2**: The second or interface float that can be enabled or disabled

**Temperature**: The ability to measure temperature that can be enabled or disabled

**Display**: The optional LCD display that can be enabled or disabled

**Alarm**: The output state that the level transmitter enters upon failure. Alarm can be Low (3.8 mA) or High (21.5 mA).

## CALIBRATION TAB



1. Changing the 4 and 20 mA set points occurs on the Calibration Tab. The procedure is the same for Level 1, Level 2 and Temperature.
2. Click 'Read' to determine current set point and units.
3. Select units from drop down menu.
4. Change set point. The 4 mA set point is the Zero or Lower Range Value (LRV). The 20 mA set point is the Span or Upper Range Value (URV).
5. Click 'Write.' Click 'Read' and confirm the new set points are correct.

The Offset field can be used for making adjustments to the optional LCD display, not the current output. This allows the display to be scaled for local viewing only.

1. Click 'R' to determine current offset
2. Enter offset in same units as set points and click 'W'
3. Click 'R' and validate offset is correct. Display should now be adjusted.

## OUTPUT TAB



**Output Mapping:** allows process variables measured by the level transmitter to be mapped to current loops of level transmitter and HART variables. Contact Technical Support for questions.

**Output Units:** The units of measure for level and temperature may be selected using the pull down menus. When changing units, these selections should be changed on this screen first, prior to changing units on any of the other tabs (Advance Setup or Calibration).

**Read:** This button sends a single read command to the transmitter and displays the data which the transmitter responds with.

**Model MR Operation and Installation Manual**

**Agency Information**

**Agency approvals**

MTS maintains IECEx, ATEX, FM, CSA, NEPSI, and other hazardous area approvals. For additional information please consult the English manual or MTS Sensors.

**KC**

**KC SPECIFIC MODEL MR NUMBER REQUIRED AS SHOWN ON PAGE 7.**

Model	Approval Type	Classification	Standard
MRK	Flameproof	Ex d IIB T4 Ga/Gb	IEC 60079-0:2012 IEC 60079-1:2007 IEC 60079-26:2007

**IP / NEMA RATING**

IEC 60529:2001 IP66

KC Installation Drawings




Figure 25. KC installation drawing

## KC INSTALLATION DRAWING NOTES

1. For field installation wiring shall be installed in accordance with the country in use.
2. Shielded twisted cable of 0.511 mm<sup>2</sup> up to 2.5 mm<sup>2</sup> max. should be used. Cable capacitance shall be less than 30 pF per 0.3m.
3. Control room equipment should not use or generate more than 250 V RMS.
4. Transmitter enclosure shall be grounded to earth through the provided ground lug in the enclosure.
5. For transmitters with dual cavity enclosures, customer connections will be made at terminal block on power side of housing and not to terminal block on interconnect board.
6. For flameproof installations, conduit seal is required within 457 mm (18 in.) of housing.

**Model MR Operation and Installation Manual**  
**Agency Information**

**KC INSTALLATION DRAWING NOTES**

Model number	Approval agency	Approval type	Approval classification	Ground connection (Figure reference)
	KTL (KC)	Flameproof		
MRK_B MRK_D	X	X	Ex d IIB T4 Ga/Gb	Figure 28
MRK_C MRK_E	X	X	Ex d IIB T4 Ga/Gb	Figure 29

**Table 5.** ATEX and IECEx model number approval classification

WIRING AND CONNECTIONS (CONTINUED)




Figure 28. Single-cavity housing




Figure 29. Dual-cavity housing

**Model MR Operation and Installation Manual**  
**Agency Information, Product Labels**

**PRODUCT LABEL IDENTIFICATION (CONTINUED)**



**Figure 32.** Product label for M-Series Models MRK\_B, C, D and E with industrial rigid pipe



**Figure 33.** Product label for M-Series Models MRK\_B, C, D and E with flexible hose

## **SPECIAL CONDITIONS FOR USE**

- The electronics housing is to be installed in zone 1 (category 2G, EPL Gb). The sensor pipe/hose may be installed in zone 0 (category 1, EPL Ga) if not restricted below.
- Equipotential bonding shall be installed inside and outside the hazardous area along the cable for supply and data.
- Float usage:
  - Metallic floats may only be used if they have a weight offset (asymmetric weight distribution).
  - Metallic floats on non-metallic pipes may not be used.
  - Aluminum floats may not be used.
- Plastic floats may only be installed in hazardous areas which require apparatus of category 1G (for zone 0) with explosion group IIA. Plastic floats may not be used on non-metallic pipes.
- Sensors with flexible measuring hoses:
  - The hose has to be mechanically protected from external impacts which may affect its function as separation wall.
  - Avoid kinking or bending the flexible hose in less than 16 inch (406 mm) diameter.
- Consult MTS if dimensional information on flameproof joints are necessary.

**Model MR Operation and Installation Manual**  
**Agency Information, KC Certificate**



**Document Part number:**  
550720 Revision I (KOR) 03/2014



## LOCATIONS

### USA

**MTS Systems Corporation  
Sensors Division**  
3001 Sheldon Drive  
Cary, N.C. 27513, USA  
Tel. +1-919-677-0100  
Fax +1-919-677-0200  
sensorsinfo@mts.com  
www.mtssensors.com

### GERMANY

**MTS Sensor Technologie  
GmbH & Co. KG**  
Auf dem Schüffel 9  
58513 Lüdenscheid, Germany  
Tel. +49-23 51-95 87 0  
Fax +49-23 51-5 64 91  
info.de@mtssensors.com  
www.mtssensor.de

### JAPAN

**MTS Sensors Technology Corp.**  
737 Aihara-machi,  
Machida-shi,  
Tokyo 194-0211, Japan  
Tel. +81-42-775-3838  
Fax +81-42-775-5512  
info.jp@mtssensors.com  
www.mtssensor.co.jp

### FRANCE

**MTS Systems SAS**  
Zone EUROPARC Bâtiment EXA 16  
16/18, rue Eugène Dupuis  
94046 Creteil, France  
Tel.: +33-1 58 43 90 28  
Fax: +33-1 58 43 90 03  
mtssensor.france@mts.com  
www.mtssensor.com

### ITALY

**MTS Systems Srl.Sensor Division**  
Via Diaz,4  
25050 Provaglio d'Iseo (BS), Italy  
Tel.: +39-030 988 38 19  
Fax: +39-030 982 33 59  
karin.arit@mtssensor.com  
www.mtssensor.com

### CHINA

**MTS Sensors**  
Room 504, Huajing Commercial Center,  
No. 188, North Qinzhou Road  
200233 Shanghai, China  
Tel: +86-21 6485 5800  
Fax: +86-21 6495 6329  
info.cn@mtssensors.com  
www.mtssensors.cn

## LEGAL NOTICES

MTS, Temposonics and Level Plus are registered trademarks of MTS Systems Corporation. All other trademarks are the property of their respective owners. Printed in USA. Copyright © 2014 MTS Systems Corporation. All Rights Reserved in all media.

All specifications are subject to change. Contact MTS for specifications and engineering drawings that are critical to your application. Drawings contained in this document are for reference only. Go to <http://www.mtssensors.com> for the latest product information.